

Ampetronic DLS

Induction Loop System

Enjoy quality sound together

If you or a member of your family is hard of hearing, then the DLS™ is just right for you. It provides excellent quality and clarity of sound normally associated with professional loop systems, direct to your hearing aid or receiver.

With 4 separate inputs, you have the flexibility to enjoy any sound source with the rest of your family at a volume that is comfortable for everyone

Ideal for use anywhere in the home or office



AMPETRONIC

Listen to the difference

How the DLS Loop System can help you

Independence - Be in control of sounds you want to hear without disturbing others

Understand every word - Providing professional audio quality sound, the clarity is superb for maximum intelligibility.

Quality of Life - Concentration is improved, tiredness and stress is reduced and listening is more enjoyable

Safety - A priority alert feature ensures that any warning signal (connected to this input) overrides the programme you are listening to.

Versatility - 4 independent inputs and a range of accessories means that you can connect the Leon DLS™ to any sound source in the home or office. You also have the flexibility to cover an area as small as a single chair to a room 30m².

Peace of mind - The DLS is backed by a 2 year manufacturers warranty. And is designed and manufactured to meet all relevant international safety and electrical standards.

Easy Installation - Supplied with easy to follow instructions, and all the accessories you need to get you started, the DLS is simple to install.



Features

4 independent inputs - Connect all your sound sources to the one system such as a television, Hi-Fi, i-pod, computer, alarm system or microphone.

Simple controls - Once the system is set up there should be no need to make any further adjustments, (You can listen at a volume that suits you without disturbing the rest of the family) but just in case you want to, there is a volume and a tone control on the front panel

Priority (VOX) input - Keep safe and never miss a caller. When a signal is present on this input, all other inputs are turned down so you will not miss it.

Headphone output - Primarily used in setting up the system and problem solving, the headphone output can also be used by those without hearing aids or loop receivers.

Starter kit - The DLS is supplied with all you need to get started - loop cable, cable clips, microphone, phono leads and easy to follow instructions.

Optional Accessories

Additional microphones and cables - Depending on just how you want to use your DLS, you may want an extra microphone or a different style eg tie-clip, goose neck or boundary mic, or additional cables to connect other equipment.

Telephone adapter - For connection between the wall outlet and telephone, or between handset and base. Allows you to use any telephone with confidence. Connected via the priority input, you will never miss a call. Full electrical isolation to international safety standards.

Chair loop - Quickly and simply loop any chair. The chair loop is placed under or behind the cushion or seat back and connects directly to the DLS. It provides a perfect signal without the need for any installation.



Listen to the difference

Ampetronic Ltd. +44 (0) 1636 610062 www.ampetronic.com
Northgate, Newark, Nottinghamshire, NG24 2ET, United Kingdom